

# craster

## PRODUCT DATA SHEET DS\_0095C

<b>Product Supplier</b>	Craster
<b>Product Name</b>	Shaker Black Range
<b>Codes</b>	SH_630_D, SH_SR002, SH_SR001, SH_SR006, SH_SR005, SH_SR009, SH_454_A, SH_223_BC, SH_223_BB, SH_223_BA, SH_SR007, SH_SR004
<b>COO</b>	Czech Republic
<b>Material</b>	Birch
<b>Finish</b>	Black Stain Lacquer
<b>Product End Use</b>	Food Presentation
<b>Declaration of Compliance</b>	This product is in compliance with EU No 10/2011 EU Article 3 1935/2004
<b>Revision Date</b>	10/12/18



### Material Information

This item is made from Birch with a Black Lacquer finish.

### Cleaning & Maintenance

Timber products should not be placed in the dishwasher.

Clean with a non-abrasive cloth using a mild detergent.

Rinse under running water to remove all detergent.

Dry by wiping off excess water with a towel, and leave to fully dry in a rack.

### Caution

DO NOT clean in the dishwasher.

DO NOT use abrasive scourers or cleaning products as this will damage the lacquer coating.

DO NOT leave to soak in water.

DO NOT use under Heat Lamps.

DO NOT use on hot plate.

### Company Address

Craster Ltd, Suite 218  
Great Western Studios, 65 Alfred Road  
London W2 5EU

### Company Info

VAT Reg No. 599599046  
Registered in England  
Company No: 4503732

### UK Telephone

+44 (0) 203 004 4750

### USA Telephone

+1 732 543 7862

### Email

info@craster.com

### Web

www.craster.com